


Rear Seat Back Cushion Latch Release Knob Bezel Replacement



Callout	Component Name
1	<div>Rear Seat Back Cushion Latch Release Handle Bezel</div> <div><b>Procedure</b></div> <div>Use a flat-bladed tool to tilt the rear of the handle upward, then lifting and pulling the bezel rearward to disengage the front hooks.</div>