


Rear License Plate Lamp Bulb Replacement (Hatchback)



Callout	Component Name
<p>Preliminary Procedure</p> <p>Remove the rear license plate lamp housing. Refer to Rear License Plate Lamp Replacement .</p>	
1	<p>License Plate Lamp Socket</p> <p>Procedure</p> <p>Rotate the electrical lamp socket a quarter turn counter-clockwise and remove from the lamp housing.</p>
2	<p>License Plate Lamp Bulb</p> <p>Procedure</p> <p>Pull the bulb straight out of the electrical lamp socket.</p>