


Rear Side Door Window Switch Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>Remove the rear side door window switch bezel. Refer to Rear Side Door Window Switch Bezel Replacement .</p>	
1	<p>Rear Side Door Window Switch Assembly</p> <p>Procedure</p> <p>1. Disconnect the electrical connectors. 2. Refer to Control Module References for programming and set up procedures.</p>