



SONIC

Installation Procedure



- 1. Install the radiator inlet hose to the vehicle.
- 2. Install the radiator inlet hose (2) to the radiator.
- 3. Install the radiator inlet hose clamp (1) at the radiator using *BO-38185* Hose Clamp Pliers .



- 4. Install the radiator inlet hose (2) to the engine.
- 5. Install the radiator inlet hose clamp (1) at the engine using *BO-38185* Hose Clamp Pliers .
- 6. Fill the cooling system. Refer to [Cooling System Draining and Filling](#)