



Installation Procedure



1. Install the heater inlet hose to the vehicle.
2. Install the heater inlet hose (2) to the engine.
3. Install the heater inlet hose clamp (1) at the engine using *BO-38185* Hose Clamp Pliers .



4. Install the heater inlet hose (2) to the heater core.
5. Connect the heater inlet hose quick connect fitting (1) at the heater core.
6. Fill the cooling system. Refer to [Cooling System Draining and Filling](#)