


Turn Signal Multifunction Switch Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>Remove the upper trim cover and the lower trim cover from the steering column. Refer to Steering Column Lower Trim Cover Replacement .</p>	
1	<p>Turn Signal Switch</p> <p>Procedure</p> <ol style="list-style-type: none">1. Disconnect any electrical connectors as necessary.2. Release the plastic retaining tabs and remove the turn signal multifunction switch from the turn signal switch bracket.