


Sunshade Replacement



Callout	Component Name
<p>Preliminary Procedure</p> <p>Lower the front of the headliner to access the sunshade electrical connector, if necessary. Refer to Headlining Trim Panel Replacement .</p>	
1	<p>Sunshade Fastener (Qty: 2)</p> <p>Caution: Refer to Fastener Caution .</p>
2	<p>Sunshade Assembly</p> <p>Procedure</p> <p>1. Squeeze the tabs at the base of the sunshade assembly to remove from the headliner. 2. Disconnect the electrical connector.</p>