



7. Loosely install the bolts (1) securing the instrument panel tie bar assembly to the brake pedal bracket.



8. Loosely install the nut (1) securing the instrument panel tie bar assembly to the cowl panel.

Caution: Refer to [Fastener Caution](#) .

- 9. Tighten the instrument panel tie bar to vehicle body bolts to **22N·m (16 lb ft)**.
- 10. Tighten the instrument panel tie bar to HVAC module fasteners to **9N·m (80 lb in)**.
- 11. Tighten the instrument panel tie bar lower support bracket to front floor tunnel panel bolts to **22N·m (16 lb ft)**.
- 12. Tighten the instrument panel tie bar to brake pedal mounting bracket nut to **22N·m (16 lb ft)**.
- 13. Tighten the instrument panel tie bar assembly to the brake pedal bracket bolts to **9N·m (80 lb in)**.
- 14. Tighten the instrument panel tie bar assembly to the cowl panel nut to **22N·m (16 lb ft)**.



- 15. Install the left floor air outlet duct (2) into the vehicle.
- 16. Install the push-pin fastener (1) securing the left floor air outlet duct (2) to the instrument panel tie bar assembly.