


Rear Seat Back Cushion Pivot Support Replacement



Callout	Component Name
<p><b>Preliminary Procedure</b></p> <p>Remove the rear seat back cushion. Refer to <a href="#">Rear Seat Back Cushion Replacement</a></p>	
1	<p>Rear Seat Back Outer Pivot Bolt (Qty: 2)</p> <p><b>Caution:</b> Refer to <a href="#">Fastener Caution</a> .</p> <p><b>Tighten</b> 23N·m (17lbft)</p>
2	<p>Rear Seat Back Cushion Outer Pivot Bushing</p>
3	<p>Rear Seat Back Cushion Outer Pivot Bolt Spring</p>
4	<p>Rear Seat Back Cushion Pivot Support Housing</p>
5	<p>Rear Seat Back Center Finish Cover</p>